



Installation Instructions


Part No. **2011**
 Product: Running Boards
 Application: **Requires Drilling**
Dodge Journey 2009+
 Level of Difficulty: 1 2 **3** 4 5
 Installation Time: 90 Min

REV 3 02/07/20

Hardware	Torque Specifications
M6 Bolt	3 ft-lbs.
M8 Bolt	7 ft-lbs.
M10 Bolt	16 ft-lbs.
M12 Bolt	28 ft-lbs.

ATTENTION: Use correct torque settings to avoid damaging the running boards and or mounting brackets. Failure to do so will void your warranty.

If you have any questions please contact our technical team at 1-866-717-6645



ITEM	PART NAME	QTY
1	2619ABNSF0 DRIVER	1
2	2619ABNSC0 DRIVER	1
3	2619ABNSB0 DRIVER	1
4	HTC 230 - M10x25(5x20x60)	4
5	HTC 262 - M10x30(5x15x60)	2
6	HTC 269 CLIPS (M10)	6
7	DIN 933 BOLT M6 x 25	6
8	DIN 6923 FLANGE NUT M10	6
9	DIN 934 NUT M6	6
10	DIN 125 WASHER	10
11	2619ABNSB0 PASSENGER	1
12	2619ABNSC0 PASSENGER	1
13	2619ABNSF0 PASSENGER	1




Installation Instructions 2011 Bracket Kit

NOTE: This installation requires drilling


Step 1: Locate front mounting locations and hardware as per 1st page of this installation manual

Step 2: Install supplied HTC 230 as show on Figure 1




Step 3: Attach front bracket as show on Figure 2 and mark position to drill Figure 3, using a 15/64 drill open a hole for the M6 bolt to go through.

Step 4: Install front bracket as shown on Figure 4, Do not tighten




Step 5: Locate middle bracket location and install supplied HTC 262 as shown Figure 5, attach middle bracket and mark position do drill Figure 3, using a 15/64 drill open a hole for the M6 bolt to go through.

Step 6: Install middle bracket as shown on Figure 6, Do not tighten




Installation Instructions 2011 Bracket Kit

Step 7: Locate rear bracket location Figure 7 and install supplied HTC 230 as shown



Step 6: Attach rear bracket and mark position do drill Figure 8, using a 15/64 drill open a hole for the M6 bolt to go through.

Step 7: Install rear bracket as shown on Figure 9, Do not tighten





Step 8: Proceed to last page of this manual for running board install instructions and torque values

For Technical support please call our team at 1-866-717-6645 and one of our experts will assist you with this installation.

Thank you for choosing Romik.

Running Board Installation Instructions



RAL / RB2 / REC / RCV / RZR



ROB / ROF / RPD

- 1) Flip your Romik running boards onto a flat surface, make sure to place the running boards on a towel or cardboard in order to protect the surface Figure 1.
- 2) Loosen the M8 bolts on back of your running boards Figure 2. Depending on your model there will be either 6 or 8 bolts installed per side.
- 3) Once your brackets have been installed, place the running board onto the brackets as shown on Figure 3.
- 4) Adjust running boards, centering on vehicle. Hand tight M8 hardware on running boards.
- 5) Follow the torque procedures, torque M8 hardware to **7 ft-lbs** using a torque wrench.
- 6) Cleaning and maintaining your running boards is important, apply a light coat of a quality carnauba wax at least 2X per year. Wash often with mild soap and make sure to remove all soap residue. Many car automatic carwashes use a strong soap, make sure to use enough water to remove all residue.
- 7) Register your products at www.Romik.com/contact/productregistration
- 8) Warranty information at www.Romik.com/warranty