



Installation Instructions

REV 3 04/01/20

Part No. **2619**

Product: Running Boards

Application:

Jeep Cherokee 2014+


Level of Difficulty: 1 2 3 **4** 5

Installation Time: 90 min

Hardware	Torque Specifications
M6 Bolt	3 ft-lbs.
M8 Bolt	7 ft-lbs.
M10 Bolt	16 ft-lbs.
M12 Bolt	28 ft-lbs.

ATTENTION: Use correct torque settings to avoid damaging the running boards and or mounting brackets. Failure to do so will void your warranty.

If you have any questions please contact our technical team at 1-866-717-6645



ITEM	PART NUMBER	QTY
1	2619850F0 DRIVER	1
2	2619850B0 DRIVER	1
3	2619850FB1 DRIVER	2
4	DIN 6921 FLANGE BOLT M8 x 25	4
5	DIN 6923 FLANGE NUT M8	4
6	DIN 6923 FLANGE NUT M10	2
7	DIN 933 BOLT M6 x 30	4
8	HTC 230 - M10x25(5x20x60)	2
9	HTC 269 CLIPS (M10)	2
10	2619850B0 PASSENGER	1
11	2619850F0 PASSENGER	1
12	2619850FB1 PASSENGER	2
13	DIN 125 WASHER M6	4



Installation Instructions 2619 Bracket Kit

Video
Installation
Instruction:

NOTE: This installation requires drilling. Cherokee Trailhawk owners can order Jeep Cherokee original side cladding 1YW36RXFAG and 1YW37RXFAG in order to install Romik running boards.

Step 1: Locate front mounting locations and hardware as per 1st page of this installation manual


Step 2: Remove factory 10mm nut Figure 1 DO NOT DISCARD.

Step 3: Attach front main bracket to factory stud. Figure 2

Step 4: Using the extra support as a guide mark the pinch weld for drilling. Place the bracket as shown on Figure 3. Drill a pilot hole 5mm Figure 4 followed by the 8mm. Clean bur if any to avoid accidents.

Step 5: Install provided 8mm hardware to hold extra support. Figure 5

Step 6: Attach extra support to main bracket using supplied M10 hardware Figure 6. Do not tighten



HINT: Sometimes it is much easier to remove factory cladding to perform these steps, be careful not to damage the plastic retaining clips as they need to be reused.


Installation Instructions 2619 Bracket Kit

Step 7: Remove factory plug in rear area Figure 7. Install provided HTC 230 as shown Figure 8.

Step 8: Attach rear main bracket as shown Figure 9

Step 9: REPEAT STEPS 4 AND 5 Figure 10

Step 10: Attach extra support to main bracket using supplied M10 hardware Figure 11. Do not tighten




Step 11: Proceed to last page of this manual for running board install instructions and torque values

For Technical support please call our team at 1-866-717-6645 and one of our experts will assist you with this installation.

Thank you for choosing Romik.

Running Board Installation Instructions



RAL / RB2 / REC / RCV / RZR



ROB / ROF / RPD

- 1) Flip your Romik running boards onto a flat surface, make sure to place the running boards on a towel or cardboard in order to protect the surface Figure 1.
- 2) Loosen the M8 bolts on back of your running boards Figure 2. Depending on your model there will be either 6 or 8 bolts installed per side.
- 3) Once your brackets have been installed, place the running board onto the brackets as shown on Figure 3.
- 4) Adjust running boards, centering on vehicle. Hand tight M8 hardware on running boards.
- 5) Follow the torque procedures, torque M8 hardware to **7 ft-lbs** using a torque wrench.
- 6) Cleaning and maintaining your running boards is important, apply a light coat of a quality carnauba wax at least 2X per year. Wash often with mild soap and make sure to remove all soap residue. Many car automatic carwashes use a strong soap, make sure to use enough water to remove all residue.
- 7) Register your products at www.Romik.com/contact/productregistration
- 8) Warranty information at www.Romik.com/warranty