



## Installation Instructions

REV 3 04/15/20

Part No. **3940 / 3941**

Product: Running Boards

Application:

Toyota 4Runner Limited 2010+

Toyota 4Runner TRD / SR5 2010+

Level of Difficulty: **1 2 3 4 5**

Installation Time: 60 min

Hardware	Torque Specifications
M6 Bolt	3 ft-lbs.
M8 Bolt	7 ft-lbs.
M10 Bolt	16 ft-lbs.
M12 Bolt	28 ft-lbs.

**ATTENTION:** Use correct torque settings to avoid damaging the running boards and or mounting brackets. Failure to do so will void your warranty.

*If you have any questions please contact our technical team at 1-866-717-6645*



ITEM	PART NAME	QTY
1	3940850F0	2
2	3940850M0	2
3	3940850B0	2
7	DIN 6921 FLANGE BOLT- M8 x 25	12

# Installation Instructions 3940 / 3941 Bracket kit

Video  
Installation  
Instruction:

**Step 1:** Locate front mounting locations and hardware as per 1<sup>st</sup> page of this installation manual. Remove factory bolts Figure 1. Install front bracket using supplied M8 hardware. Do not tighten



**Step 2:** Locate middle bracket mounting location Remove factory bolts Figure 2. Install middle bracket using supplied M8 hardware. Do not tighten




**Step 3:** Locate rear bracket mounting location Remove factory bolts Figure 3. Install rear bracket using supplied M8 hardware. Do not tighten



**Step 4:** Proceed to last page of this manual for running board install instructions and torque values For Technical support please call our team at 1-866-717-6645 and one of our experts will assist you with this installation.

**Thank you for choosing Romik**

# Running Board Installation Instructions



**RAL / RB2 / REC / RCV / RZR**



**ROB / ROF / RPD**

- 1) Flip your Romik running boards onto a flat surface, make sure to place the running boards on a towel or cardboard in order to protect the surface Figure 1.
- 2) Loosen the M8 bolts on back of your running boards Figure 2. Depending on your model there will be either 6 or 8 bolts installed per side.
- 3) Once your brackets have been installed, place the running board onto the brackets as shown on Figure 3.
- 4) Adjust running boards, centering on vehicle. Hand tight M8 hardware on running boards.
- 5) Follow the torque procedures, torque M8 hardware to **7 ft-lbs** using a torque wrench.
- 6) Cleaning and maintaining your running boards is important, apply a light coat of a quality carnauba wax at least 2X per year. Wash often with mild soap and make sure to remove all soap residue. Many car automatic carwashes use a strong soap, make sure to use enough water to remove all residue.
- 7) Register your products at [www.Romik.com/contact/productregistration](http://www.Romik.com/contact/productregistration)
- 8) Warranty information at [www.Romik.com/warranty](http://www.Romik.com/warranty)