



# Installation Instructions


Part No. **2623**  
 Product: Running Boards  
 Application:  
 Jeep Compass 2017+  
 Level of Difficulty: **1 2 3 4 5**  
 Installation Time: 60 min

REV 3 04/02/20

Hardware	Torque Specifications
M6 Bolt	3 ft-lbs.
M8 Bolt	7 ft-lbs.
M10 Bolt	16 ft-lbs.
M12 Bolt	28 ft-lbs.

**ATTENTION:** Use correct torque settings to avoid damaging the running boards and or mounting brackets. Failure to do so will void your warranty.

If you have any questions please contact our technical team at 1-866-717-6645



ITEM	PART NAME	QTY..
1	2623850F0	2
2	2623850B0	2
3	2623850BF1	4
7	HTC 226 - M8X30 (4X10X37)	4
8	HTC 262 - M10x30 (5x1 5x60)	4
9	HTC 271 KLIPS (M8)	4
10	HTC 269 KLIPS (M10)	4
11	DIN 6921 Flange Bolt - M10 x 25	4
12	DIN 6923 Flange Nut - M8	4
13	DIN 6923 Flange Nut - M10	8



# Installation Instructions



**NOTE:** Due to vehicle design, there is a large gap between the running boards and the body cladding. **DO NOT** install without first consulting the customer or visiting [www.Romik.com](http://www.Romik.com) to view images.

**Step 1:** Locate front mounting locations and hardware as per 1<sup>st</sup> page of this installation manual

**Step 2:** Remove factory rubber plug Figure 1 install HTC 262 Figure 2



**Step 3:** Remove factory tape on extra support area, this is an opening in the vehicle cladding Figure 3. Hint use a screw driver to “poke” and find the tape. Install HTC 226 as shown Figure 4. Install extra support as shown.

**Step 4:** Install main front support Figure 5, attach extra support to main support using provided M10 hardware. Do not tighten



**Step 4:** Remove factory rubber plug in rear bracket area. Figure 7 install HTC 262 as shown Figure 8

**Step 5:** Remove Remove factory tape on extra support area, this is an opening in the vehicle cladding Figure 9, 10. Hint use a screw driver to “poke” and find the tape. Install HTC 226 as shown Figure 11. Install extra support as shown Figure 12.



# Installation Instructions

---

**Step 6:** Install main rear support Figure 13, attach extra support to main support using provided M10 hardware Figure 14. Do not tighten





**Step 7:** Proceed to last page of this manual for running board install instructions and torque values

For Technical support please call our team at 1-866-717-6645 and one of our experts will assist you with this installation.

***Thank you for choosing Romik.***

# Running Board Installation Instructions



**RAL / RB2 / REC / RCV / RZR**



**ROB / ROF / RPD**

- 1) Flip your Romik running boards onto a flat surface, make sure to place the running boards on a towel or cardboard in order to protect the surface Figure 1.
- 2) Loosen the M8 bolts on back of your running boards Figure 2. Depending on your model there will be either 6 or 8 bolts installed per side.
- 3) Once your brackets have been installed, place the running board onto the brackets as shown on Figure 3.
- 4) Adjust running boards, centering on vehicle. Hand tight M8 hardware on running boards.
- 5) Follow the torque procedures, torque M8 hardware to **7 ft-lbs** using a torque wrench.
- 6) Cleaning and maintaining your running boards is important, apply a light coat of a quality carnauba wax at least 2X per year. Wash often with mild soap and make sure to remove all soap residue. Many car automatic carwashes use a strong soap, make sure to use enough water to remove all residue.
- 7) Register your products at [www.Romik.com/contact/productregistration](http://www.Romik.com/contact/productregistration)
- 8) Warranty information at [www.Romik.com/warranty](http://www.Romik.com/warranty)